




MODEL 1000 DOUBLE PLANETARY WHEEL DRIVE SERVICE MANUAL



WARNING: While working on this equipment, use safe lifting procedures, wear adequate clothing and wear hearing, eye and respiratory protection.

THIS SERVICE MANUAL IS EFFECTIVE:
S/N:25000 TO CURRENT
DATE:02/01/1996 TO CURRENT
VERSION: SM1000LW2-AB



NOTE: Individual customer specifications (mounting case, output shaft, brake assembly, etc.) may vary from exploded drawing and standard part numbers shown. If applicable, refer to customer drawing for details.





MODEL 1000L WHEEL DRIVE

EQUIPPED WITH PATENTED "LOAD-LOCK" SHAFT RETENTION SYSTEM (U.S. PATENT NO. 5,746,917).
 *UNITS MANUFACTURED PRIOR TO SN75300
 UTILIZE (OBSOLETE) PIN 60-004-1301 FOR ITEM 22.
 **USE OF PIN 60-004-1881 WILL MAKE OLDER UNITS UNABLE TO CURRENT UNIT (SHOWN ON THIS DRAWING).
 EFFECTIVE FROM SN 70500 08-01-08 TO (CURRENT)

NOTES:
 1. BEARING PRELOAD DETERMINES QUANTITY OF SHIMS.
 2. SEAL KIT (PIN 60-016-210)
 INCLUDES:
 3 EA. ITEM (39) O-RINGS,
 1 EA. ITEM (49) SEAL, AND
 1 EA. ITEM (60) SEAL BOOT.



X1000LW2-AC,
Page 1 of 2
Effective date 08/01/2006
Effective serial # 70500

		MODEL 1000L WHEEL DRIVE		RATIOS →		SIMPLE PLANETARY		COMPOUND PLANETARY
								
ITEM	QTY.	DESCRIPTION	PART NUMBER	PART NUMBER	PART NUMBER			
1	1	CODE F - FLANGELESS	60-004-3034		60-004-3034			
		CODE A - FLANGED	60-004-3044		60-004-3044			
		CODE C - CUSTOM						
2	1	COVER	60-004-1444		60-004-1444			
3	1	CODE W1C - 17" DIA.; 12X 1 1/8 - 12 UNF - 2B	60-004-4172L		60-004-4172L			
		CODE W1D - 17" DIA.; 12X 1 1/8 - 12 UNF - 2B	60-004-4072L		60-004-4072L			
		CODE WC1 - CUSTOM						
5	1	CARRIER - SECONDARY	60-004-1044		60-004-1044			
6	1	CARRIER - PRIMARY	60-004-1372	60-004-1722	60-004-1722			
7	1	RING GEAR - SECONDARY	60-004-1243		60-004-1243			
8	-	RING GEAR - SIMPLE PRIMARY	60-004-1193		-			
9	1	RING GEAR - COMPOUND PRIMARY	-	-	60-004-1213			
10	1	RING SPACER - PRIMARY	-	-	60-004-1253			
11	3	PLANET GEAR - SECONDARY	60-004-1232		60-004-1232			
12	-	PLANET GEAR - PRIMARY	60-004-1132	60-004-1152	-			
13	3	CLUSTER GEAR	-	-	60-004-1162			
14	1	LOCK RING	60-004-1472		60-004-1472			
15	-J-	SHIM(S) - SHAFT	60-004-1311		60-004-1311			
16	1	SECONDARY SUN GEAR	60-004-1362		60-004-1362			
17	1	PRIMARY SUN GEAR (13T; 8/16 SPLINE) HOLLOW SPIND.	60-004-1382	60-004-1812	60-004-1812			
18	3	PLANET SHAFT-SECONDARY	60-004-1262		60-004-1262			
19	3	PLANET SHAFT-PRIMARY	60-004-1272		60-004-1272			
20	-J-	SHIM(S) - SECONDARY PLANET	60-004-1321		60-004-1321			
21	6	WASHER - SECONDARY PLANET	60-004-1291		60-004-1291			
22	6	WASHER - PRIMARY PLANET	60-004-1301		60-004-1301			
23	1	BEARING CONE - SHAFT OUTER	01-102-0190		01-102-0190			
24	1	BEARING CUP - SHAFT OUTER	01-103-0190		01-103-0190			
25	1	BEARING CONE - SHAFT INNER	01-102-0230		01-102-0230			
26	1	BEARING CUP - SHAFT INNER	01-103-0230		01-103-0230			
27	6	CONE - SEC.PLANET	01-102-0210		01-102-0210			
28	6	CUP - SEC.PLANET	01-103-0210		01-103-0210			
29	6	BRG-PRIMARY PLANET	01-105-0510		01-105-0510			
30	1	BRG-PRI. CARR. THRUST	01-112-0340		01-112-0340			
31	2	RACE-PRI. CARR. THRUST	01-112-0350		01-112-0350			
33	3	O-RING - RING GEAR	01-402-0660		01-402-0660			
35	1	SPLIT RING	60-004-1482		60-004-1482			
36	3	RETAINING RING - SEC. PIN	01-160-0490		01-160-0490			
37	6	RETAINING RING-SEC. PLNT.	01-160-0500		01-160-0500			
39	6	ROLL PIN - PRI. 1/4 X 1 3/8	01-153-0150		01-153-0150			
41	1	PIPE PLUG 1/4 NPT	01-207-0020		01-207-0020			
42	6	PIPE PLUG 3/4 NPT MAGNETIC	01-207-0100		01-207-0100			
43	20	H.H.C.S 3/4-10 X 10.5 GRD 8	01-150-1580		01-150-1580			
45	12	S.H.C.S 1/2-13 X 1.5 GRD 8	-		01-150-0570			
46	20	LOCKWASHER - 3/4	01-166-0360		01-166-0360			
47	1	RING - SEC CARRIER RETAINER	60-004-1352		60-004-1352			
48	3	FLAT HD. SOC. C.S. 3/8-24 X 1 GR8	01-150-1590		01-150-1590			
49	1	SEAL - METAL FACE	01-406-0010		01-406-0010			
50	1	SEAL - RUBBER FACE	01-406-0020		01-406-0020			
51	1	PIPE PLUG (1/8 NPT-HOLLOW HEX)	01-207-0030		01-207-0030			
52	1	GREASE FITTING-STRAIGHT, 1/8 NPT	01-215-0010		01-215-0010			
53	(1)	CODE 3 : 14T, 12/24 D.P., LONG SHAFT (OPTIONAL)	98-005-1141		98-005-1141			
		CODE 4 : 14T, 12/24 D.P. (OPTIONAL)	60-004-1943		60-004-1943			
		CODE 7 : 17T, 12/24 D.P. (OPTIONAL)	60-004-1944		60-004-1944			
54	(1)	CODE V - AIR VENT; (#301370) ALEMITE, 1/8"NPT (OPT.)	01-216-0030		01-216-0030			
55	(1)	ADAPTER; 3/4" NPT-M, 1/8" NPT-F (OPTIONAL)	01-201-0530		01-201-0530			
56	1	BALL BEARING (7207 WN)	01-100-0320		01-100-0320			
57	1	O - RING	01-402-0220		01-402-0220			
58	1	THRUST HUB	60-004-1822		60-004-1822			
59	6	SHCS (1/4-20 X 1/2 GR8)	01-150-0560		01-150-0560			
60	1	INPUT SHAFT - 13T HOLLOW SPINDLE	60-004-1392		60-004-1392			
61	1	CODE 4, 7 & 8 : 16T, 8/16 D.P. INPUT COUPLING	60-004-1422		60-004-1422			
		CODE 3 & 9 : 13T, 8/16 D.P. INPUT COUPLING	60-004-1692		60-004-1692			
62	2	RETAINING RING	01-160-0580		01-160-0580			
63	1	RETAINING RING	01-160-0060		01-160-0060			
64	1	PLUG SAE #14 (MODELS W/OUT DISCONNECT OPTION)	01-208-0080		01-208-0080			
		DISCONNECT OPTION KIT (INCLUDES ITEMS D1-D6)	60-005-2143		60-005-2143			
D1	1	DOWEL PIN (5/8 x 3-1/2)	01-152-0130		01-152-0130			
D2	1	SPRING 6.0 x .75 x 23 lb/in	01-261-0550		01-261-0550			
D3	1	DISCONNECT PLATE	600-004-1832		600-004-1832			
D4	2	HHCS; 5/16-18 x 1 GR5	01-150-1790		01-150-1790			
D5	2	LOCKWASHER (5/16)	01-166-0110		01-166-0110			
D6	1	O-RING	01-402-0900		01-402-0900			

X1000LW2-AC,

Page 2 of 2


Effective date 08/01/2006

Effective serial # 70500

LUBRICATION & MAINTENANCE

Using the chart below, determine an appropriate lubricant viscosity. Use only EP (extreme pressure) or API GL-5 designated lubricants. Change the lubricant after the first 50 hours of operation and at 500 hour intervals thereafter. The gear drive should be partially disassembled to inspect gears and bearings at 1000 hour intervals.

Recommended ambient and operating temperatures for conventional and synthetic gear lubricants



Note: Ambient temperature is the air temperature measured in the immediate vicinity of the gearbox. A Gearbox exposed to the direct rays of the sun or other radiant heat sources will operate at higher temperatures and therefore must be given special consideration. The max operating temp must not be exceeded under any circumstances, regardless of ambient temperature.

ESKRIDGE MODEL 1000 OIL CAPACITIES

Operating Position		Oil Capacity			Oil Level	
		Single stage	Double stage	Triple stage		
	Horizontal Shaft	-	17 qts / 16 Liters	18 qts / 17 Liters	To horizontal centerline of gear drive	
	Vertical Shaft (Pinion Up)	-	-	-	To side port on gear drive base	
	Vertical Shaft (Pinion Down)		29 qts / 27 Liters	30 qts / 28 Liters	To midway on upper/primary gear set	

ESKRIDGE PART NUMBER INTERPRETATION

Note: All standard Eskridge Geardrives are issued a descriptive part number which includes information regarding the Model, means of shaft retention, base style, shaft style, input mounting, input shaft size, overall ratio and various available options. For a detailed breakdown of this information, please refer to Eskridge product specification sheets found at: <http://www.eskridgeinc.com/geardrives/gearprodspecs.html>

Unit Teardown

- 1) Scribe a diagonal line across the outside of the unit from the cover (2) to the base (1) before disassembly to aid in the proper positioning of pieces during reassembly.
- 2) Remove drain plugs (42) and drain oil from unit. The oil will drain out more quickly and completely if warm.
- 3) Remove the 20 3/4-10 capscrews (43) and lockwashers (46) retaining the cover (2).
- 4) Remove the cover (2), thrust washer(s)/bearing(s) (30,31,32), and input gear (17). Inspect o-ring (33); discard if damaged or deformed.
- 5) Lift the planet carrier assembly out of the unit .
- 6) Remove ring gear(s)/spacer (8/10pri, 7sec), input shaft (60) and subsequent carrier assemblies. Inspect gear to gear and gear to base O-ring(s) (33); as before, discard if damaged or deformed.
- 7) The unit is now disassembled into groups of parts. The area(s) requiring service should be identified by thorough inspection of the individual components after they have been cleaned and dried.

Carrier Assembly Teardown

Rotate planet gears (12/13 pri;11 sec) to check for abnormal noise or roughness in bearings. If further inspection or replacement is required, proceed as follows.

- 1) *Primary:* Drive roll pins (39) completely into the planet shafts (19). *Secondary:* Remove planet shaft retaining rings (36), spacers (21) and preload shims (20)
- 2) Slide planet shafts (19 pri/18 sec) out of carrier.
- 3) Remove planet gears (12/13 pri; 11 sec), washers (22 pri/21 sec) and bearings (29 pri;27/28 sec) from carrier (6).
- 4) Inspect the planet gear (12/13 pri; 11 sec), bearing bore and planet shaft (19 pri/18 sec) and bearings (29 pri; 27/28 sec). Check for spalling, bruising or other damage and replace components as necessary.
- 5) *Primary only:* Remove roll pins (39) from planet shafts (19) using a 1/4 inch pin punch.

Carrier Reassembly

- 1) *Primary:* Planet shafts (19) should be installed with chamfered end of 1/4 inch roll pin hole towards outside diameter of carrier (6); this will ease alignment of holes while inserting roll pins (39). *Secondary:* Planet shafts must be installed aligning the slot in the large end of the shaft with the roll pin protruding into the shaft bore.
- 2) *Primary:* Drive roll pin (39) into the carrier hole and into planet shaft to retain parts. *Secondary:* Install the first planet washer (21) to the small end of the planet shaft, the appropriate number of preload shims (20) and then the second planet washer (21) and retaining ring (36) Repeat for remaining planet gears.

Base Subassembly Teardown

- 1) Remove the output shaft lock ring (14) using a heel bar or puller; if using a heel bar, be sure not to pry against the cage of the inner spindle bearing (25). Remove the split ring segments (35) and shims (15).

Caution: Since the shaft is no longer positively retained, care should be taken to avoid injury. Care should also be taken not to damage it while pressing through base.

- 2) Place base (1) exterior side down, on a plate or table. Press output shaft out bottom of base by applying a load to internal end of spindle (3) until it passes through inner spindle bearing cone (25).
- 3) A gear puller may be used to remove the outer bearing cone (23) from the spindle (3). If reusing old bearing cone, do not pull on or damage roller cage.

Note: Press bearing cone onto output spindle by pressing on inner race only. DO NOT press on roller cage, as it may damage the bearing assembly.

- 4) Inspect inner and outer bearing cups (26 & 24). If cups are damaged they must be replaced, drive them out using a brass drift and utilizing the bearing knock-out notches in the base (1)

Base Reassembly

- 1) Clean all foreign material from magnetic oil plugs located In base (1).
- 2) Place base exterior side up on work table.
- 3) Apply a layer of lithium or general purpose bearing grease to the roller contact surface of outer bearing cup (24).
- 4) Press outer bearing cone (23) onto the spindle (3) until it seats against the shoulder.
- 5) Wipe the face of each half of the metal face seal (49) using a lint-free wipe. No particles of any kind are permissible on the sealing surfaces. (Even a hair is sufficient to hold the seal surfaces apart and cause a leak.) Apply a thin film of oil on the entire seal face of one or both seals using a clean finger or lint-free applicator. Oil must not contact any surfaces other than the sealing faces. (See Pages 6-8 for seal inspection and service procedures.)
- 6) Place the spindle (3) with the outer bearing cone into the base.
- 7) Flip shaft/base assembly, and apply lithium or general purpose bearing grease to roller contact surface of the inner cup (26), then press inner bearing cone (25) onto shaft until it seats against inner bearing cup.
- 8) Proper spindle bearing preload will result in a rolling torque which varies between 200 to 300 in-lb. The bearing preload should be tailored to your application; a low-speed application may require a high pre-load, while high-speed applications usually benefit from low pre-load. Adding shims (15) will increase the pre-load on the bearing set. Determine your pre-load requirement and install shims to obtain this pre-load.
- 9) Install the Load-N-Lock™ halves (35) over the shims and into the corresponding spindle groove. Then, install the lock ring (14) over the Load-n-Lock halves (35B).

All subassembly service or repairs should be complete at this time. Continue to Unit Assembly to complete buildup of unit.

Unit Reassembly

- 1) Install the secondary carrier assembly onto the output spindle; aligning the splines of the carrier (5) with the output spindle (3) splines and centering the three threaded holes in the output spindle between the planet gears. Once aligned slide the carrier onto the spindle.
- 2) Install carrier retaining plate (47) & secure using provided 3/8-24 Flathead capscrews (48). If using thread locking compound to assist in screw retention, apply only a small amount to internal threads. Use of excess thread lock may cause screws to be irremovable once compound has cured.
- 3) Lubricate o-ring (33) and install on the ring gear (7) pilot.

Caution: Hold ring gear by outside diameter or use lifting device to prevent injury.

- 4) Align the gear teeth of secondary ring gear (7) with the gear teeth of the planet gears (11) and place ring gear on base aligning mounting holes of ring gear with holes in base. Use the scribed line made during disassembly for reference. With carrier in place, install secondary sun gear (16) and input shaft (60).

Simple Planetary Primary, for compound primary skip to step 5C

- 5S) Install primary ring gear (with lubricated o-ring in place), align mounting holes of ring gear with holes in base using the scribed line made during disassembly for reference. Install the primary carrier assembly aligning gear teeth of ring gear with those of the planet gears and place on base. Install the input gear (17) and input shaft (60).

Compound primary (76:1 ratio and up):


- 5C) a) The planet gears will now need to be timed. Refer to the diagram appropriate for your unit's gear ratio (above, right). The planet gears each have a timing mark, usually a round punch mark stamped into the surface which is shown as a circle on the diagram.
 - b) As seen from above, start with the top planet gear with its timing mark pointing straight down. Next, rotate the lower left planet gear counterclockwise as indicated in the timing diagram. Then rotate the lower right planet gear clockwise as indicated.
 - c) Set the input gear (17) and the input thrust race (32) into the center of the primary planet carrier assembly.
 - d) If compound primary ring gear (9) was not removed during disassembly, then skip to step 7. Otherwise, bolt to the inside of the cover (2) with twelve bolts (45). Use a removable thread locking compound on the threads of the bolts (45). Tighten to 110 ft.-lbs. dry or 80 ft.-lbs. lubricated.
 - e) Install primary ring spacer (10) w/ O-ring (33) in place.
- 6) Install the input to cover thrust washer (32) and carrier to cover thrust washers (31, 2ea; 30, 1ea) Refer to exploded view for details.
 - 7) Noting the scribed line made during disassembly, (with lubricated o-ring in place) align and install the cover (2). If unit is equipped with disconnect option, care must be taken to ensure

that the disconnect pin (D1) is properly seated in the thrust hub (58) before the cover is installed to unit.


- 8) Install and torque the 20 3/4-10 hex-head cap-screws (43) with lockwashers (46). The torque for the cap-screws: 380 ft-lb dry, 280 ft-lb if the fasteners are lubricated.
- 9) Using a splined shaft to drive the input gear (17) ensure that the unit spins freely.
- 10) Fill the unit to the proper level, as specified, with recommended gear oil (refer to chart, page 3) after unit is sealed with brake and/or motor.

The gearbox is now ready to use. The gear drive is now ready to use.

PRIMARY CARRIER TIMING DIAGRAMS



UNIT RATIO
76:1



UNIT RATIO
96:1

Inspection of Worn Seals

Seals wear in an axial, rather than radial, direction (as depicted in Figure Y). The total thickness of the flange is usable wear material on the formed seal rings and good seal performance can generally be expected until the flange is completely worn away. Remaining service life can be estimated by measuring the ring flange thickness, and using the chart below. Minimum flange thickness required for reusability is 0.05" (1.27 mm).




Figure Y

The measured parameter used to check the remaining seal life is flange thickness, at the outer edge (once any wear lip is removed). The measurement must be made carefully because the shoulder is only 0.06" (1.52 mm) from the edge of the flange.

Estimates of expected seal life are difficult, because there are many differences in machine applications, job conditions, maintenance and other factors that affect seal service life.

Formed Seal Wear Chart	
Flange Thickness in (mm)	Seal Wear Percent Worn
0.075 (1.91)	0
0.062 (1.59)	25
0.050 (1.27)	50
0.038 (0.95)	75
0.025 (0.64)	100
0.012 (0.32)	125
0.000 (0.00)	150


Mishandling Of Seals

Mishandling of seals during assembly can cause immediate leaks or premature failure. Failure can occur due to cutting or tearing of the elastomeric load ring, breakage of the sealing ring, contamination of the sealing face with dirt or lint, etc. When assembling metal face seals, please carefully observe assembly instructions.

Housing Preparation

The housing components (3, 4) that contact the rubber toric rings must be free from foreign material (oil, grease, dirt, metal chips dust or lint particles, etc.) before installing the seal. This should be done with a lint-free wipe and a non-petroleum based solvent.

- 1) Remove any foreign material from the rubber torics (2), ramps (7) and lips (8) of both seal rings. This should also be done with a lint-free wipe and non-petroleum based solvent.
- 2) Dry with a clean wipe.
- 3) Place the rubber toric (2) on the metal seal ring (6) at the bottom of the seal ring ramp (7) and against the retaining lip (8) (see illustration on previous page). Make sure the rubber toric is straight on the seal ring and not twisted. Be careful not to nick or cut the torics during this assembly, as this can cause leaks.
- 4) Put the installation tool (9) onto the metal seal ring (6) and rubber toric (2). Lightly dampen the lower half of the rubber toric with the appropriate assembly lubricant. Techniques to dampen the toric include wiping with a lint-free towel, lubricating using a clean foam brush, or dipping into a container lined with towels saturated in the assembly lubricant (as shown).



Approved Assembly Lubricants*

Isopropyl Alcohol


Houghto-Grind 60 CT

Quaker® Solvo Clean 68-RAH

***Do not use Stanosol or any other liquid that leaves an oil film or does not evaporate quickly.**

Installation Process

- 1) With the lower half of the rubber toric still wet, use the installation tool (9) to position the seal ring (1) and the rubber toric (2) squarely against the housing retainer lip (3) (as shown).
- 2) For smaller diameter seals, use sudden and even pressure to push the rubber toric under the retaining lip of the housing. For larger diameter seals, which will not press in with sudden and even pressure, it is acceptable to work the toric past the retaining lip by starting on one side and tapping the opposite side of the installation tool with a rubber mallet until it is engaged past the retaining lip of the housing.
- 3) Check the assembled height (A) (see below) in at least four places, 90° apart, using either a caliper, tool makers' ruler or any other calibrated measuring device. The difference in height around the ring must not be more than 0.04" (1 mm). If small adjustments are necessary, do not push or pull directly on the seal ring. Use the installation tool (9) to push down and your fingers to pull up uniformly on the rubber toric and seal ring.




NOTE: The rubber toric can twist if it is not completely wet during installation or if there are burrs or fins on the retaining lip of the housing. Twists, misalignments and bulges of the toric will result in seal failure. If correct installation is not apparent, remove seal from the housing and repeat the process.

The rubber toric must never slip on the ramps of either the seal ring or the housing. To prevent slippage, allow adequate evaporation time for the lubricant before proceeding with further assembly. Once correctly in place, the rubber toric must roll on the ramp only.

- 4) Wipe each seal ring face (6) using a lint-free wipe. No particles of any kind are permissible on the sealing surfaces. (Even a hair is sufficient to hold the seal surfaces apart and cause a leak.)
- 5) Apply a thin film of oil on the entire seal face (6) of one or both seals using a clean finger or lint-free applicator. Oil must not contact surfaces other than the sealing faces.

NOTE: Mishandling of seals during assembly can cause immediate leaks or premature failure. Failure can occur due to curing or tearing of the elastomeric load ring, breakage of the sealing ring, contamination of the sealing face with dirt or lint, etc. When assembling metal face seals, please carefully observe assembly instructions.



Final Assembly

While completing the final assembly of the unit, make sure that both housings are in correct alignment and are concentric. Slowly bring the two housings together. High impact can scratch or break the seal components.

If the rubber toric slips at any location, it will twist, causing the seal rings to cock. Any wobbling motion of the seal is an indication of cocked seals and can cause dirt to enter by pumping mud past the torics.